


# ***SEAVIEW***///




## ***INSTALLATION INSTRUCTIONS***

For Seaview Spreader LED Floodlight Kit:


***SP-LT-LED***

Refer to website for most up to  
date instructions and videos.

***WWW.SEAVIEWGLOBAL.COM***




x1




x1







x1




x2




x2




1




2




3




4



5



6



The background of the entire page is a light gray topographic map with white contour lines. The lines are irregular and wavy, representing elevation changes across a landscape. The map is centered and covers the entire area.

***SEAVIEW***///  
***ELEVATE YOUR ELECTRONICS***

***SEAVIEW***///

Tel: 800-655-7922  
[www.seaviewglobal.com](http://www.seaviewglobal.com)

***EUROPEAN OFFICE***

Tel: +33 4 94 53 27 70  
[www.seaviewprogress.com](http://www.seaviewprogress.com)